



Operating direction

ホバリング・上昇・下降




左スロットルレバー上下で上昇・下降

前進・後進




右コントロールレバー上下で前進・後進

左右転回




右コントロールレバーで左右転回

旋回飛行




左スロットルレバー左右で旋回飛行

Forward/Backward fine-tuning




When the quadcopter keeps flying forward / backward, you can correct it by pressing the fine-tuning button down / up.

Sideward fly fine-tuning



When the quadcopter keeps flying to left / right side, you can correct it by pressing the fine-tuning button right / left.

Turn left/right fine-tuning



When the quadcopter keeps rotating to left / right, you can correct it by pressing the fine-tuning button right / left.